

BLOWER USER MANUAL

1. safety instructions

This blower for commercial usage or home usage only. This product is suitable for use in indoor environment.

Before using this product, please carefully read and understand all the contents of this manual Labeling on the product. Please remain vigilant during product use and follow instructions. The operation of the content in the manual will ensure the safety of you and your family. Please kee p it safe. This manual is for future use and product maintenance. Any guidelines related to the instruction manual. Any operation that does not match the content may result in serious personal injury or damage to the product.

Causing damage on its own. Due to failure to follow the instructions in this manual The loss is not covered by the warranty of this product.

2. Points to note about the use of this product

The rated voltage of this product is 220V~single-phase AC, and the rated frequency is 50Hz Quasi mains power supply, please do not use power sources that do not match the rated voltage and frequency;

If damage is found to the power cord or plug, the power socket is loose, and the power plug Do not use this product when it does not match the socket, otherwise it may cause electric shock or Overheating can cause a fire;

This product should not be used by children or individuals with mental disorders to avoid lack of compatibility

Individuals with experience and knowledge are required to use it, and a dedicated person is respon sible for supervising and guiding their safety

Fully use this product;

Do not use this machine in workplaces with harsh environments such as large dust and oil fumes.

Do not pull the power cord at sharp edges and corners to prevent damage;

Before each use of this floor blower, please carefully check the power supply and other component s.

Is there any damage or aging phenomenon? If the power cord is damaged or exposed, please do n ot use this product.

Products to avoid the risk of electric shock to your body;

3. Machine spec.

Serials	MODEL	POWER	VOLTAGE	Air Volume	Max Wind Speed	Applicable Area
220A	741726OR-MLE	330W	110-120V 60HZ	1900/1700/1500 m³	15/14/12m/s	60 m²
220A	741726BL-MLE	330W	110-120V 60HZ	1900/1700/1500 m ³	15/14/12m/s	60 m²
250A	741727OR-MLE	350W	110-120V 60HZ	2000/1800/1600 m ³	16/15/13m/s	60 m²
250A	741727BL-MLE	350W	110-120V 60HZ	2000/1800/1600 m ³	16/15/13m/s	60 m²

Safety instructions

Warning!!!

Do not move or pull the product during use.

Prohibit children from playing with all kinds of packaging materials, which may lead to the risk of suffocation.

Do not allow children to handle this product, prevent children from playing with this product, avoid the cause.

The guardian shall strengthen the role of guardianship and supervision over the personal injury caused by this.

This product should be placed horizontally and placed on a relatively stable surface for use To prevent injury to personnel or the machine itself due to falling or tipping of the machine. Clothing, ties, scarves, etc. that may be sucked should be prohibited in the surrounding environment during use.

Items entering the machine to avoid unnecessary losses as a result.

Do not use this product in any dusty environment as there is a risk of explosion and burning.

Notice:

Before use, observe whether the entire machine is intact, whether the power cord is damaged, and whether the wind turbine is intact.

Observe whether there are foreign objects entangled during use. If there are foreign objects entangled, they should be closed in a timely manner

Send the machine to the designated after-sales service center for maintenance and cleaning.

After use, observe whether there are foreign objects on both sides of the air inlet and outlet of the entire machine

Block and send to the designated after-sales service center for repair and cleaning.

If the plug or power cord is damaged, to avoid danger and cause greater losses, please do not self destruct.

Maintenance and replacement must be carried out by professionals authorized by the manufacturer; If the floor blower fails to function properly, or falls or is damaged during use, or

In case of outdoor moisture, water ingress, etc., please leave it before the next use.

Send to a professional repair point for inspection and repair, confirm the safety of the product befor e normal use. When cleaning and maintaining this product, please turn off the product switch in adv ance and unplug the plug in a timely manner. Do not use in water pools, low-lying areas, or similar p laces, and do not immerse the product in any liquid. Do not use damp objects to come into contact with the power cord plug or this product to prevent.

As a result, leakage and electric shock occurred, and electrical short circuits led to fire incidents.





Speed Adjustor from 1-3 speed

Problem	Reasons	Solutions
Blower not work	1.check power plug if connect well 2.Check if the socket is powered on 3.Foreign objects inhaled inside the ma chine or insert 4.Damaged power cord and other origin al issues .	1. Reconnect the power cord plug 2. Check if the power supply h as power 3. Remove the plug and check the power cord Is there any abnormal situation with the machine, Send to the professional aftersales service center Line maintenance
The blower emits a pier cing sound during oper ation	1.Objects inhaled or inserted inside the machine 2. Abnormal damage to the entire machine leads to deformation and damage of parts	Excluding objects while ensuring safety during shutdown Timely send to a profession al after-sales service center for repair and maintenance
Over shaking	There is a large amount of dust accumulation on the wind turbine There are foreign objects entangled on the wind turbine	On the premise of shutting down to ensure safety Timely delivery of professional after-sales service Heart to heart maintenance and repair